

xTool F2

175 x 237 mm | 6.89 x 9.33 in | A4

MXF-K005-002 body only; no Slide Extension

1. Print this page first: Actual size / 100%, single-sided, one page per sheet. No Fit or Shrink.
2. Measure both axes of the 50 mm square and the 100 mm bar below. If wrong, fix scaling.
3. Print all tiles with the SAME settings. Check each tile's 50 mm bar. Trim dashed borders.
4. Match row/column labels. Butt tile edges with NO gap or overlap; tape from behind.
5. Measure the assembled dark rectangle: 175 x 237 mm. Do not measure the tile borders.

ASSEMBLY MAP (NOT TO SCALE)

R1C1
R2C1

1 column x 2 rows


2 tiles + this guide

Dashed: trim border

Heavy solid: machine body

Light grid: 50 mm spacing

CALIBRATION / MEASURE BEFORE ASSEMBLING



Next: check your room

laserroomready.com


Scan for this machine's checker

Source checked 2026-09-16: <https://support.xtool.com/article/2013>

Planning rectangle from product dimensions. No feet, lid travel, service, hose or accessory space.

Organizational aid, not engineering, safety approval or code certification. Remove paper before use.

Original layout: LaserRoomReady, CC BY 4.0. Preserve source/date/limits. Not endorsed by xTool.



Trim dashed border. Butt edges, no overlap. 5 mm outer padding is NOT clearance.

R2C1 / global x 0, y 230 mm			

Trim dashed border. Butt edges, no overlap. 5 mm outer padding is NOT clearance.